

6-10
YEARS

B-TRIKE^{G2}

CONSTRUCTION MANUAL



Length 120 - 140 cm / 47 - 55 inch
Max weight 40 kg / 88 lbs
Time to build 6 hours



World's first real constructible rides



WARNING - IMPORTANT NOTICE TO PARENTS

Before you start constructing and use our product, please carefully read the following safety warning and download our manual from our website. This safety warning and manual contains important information relating to your child's safety. It is your responsibility to review this information with your child and make sure they are fully aware of all the warnings before they start riding. Failure to follow instructions and safety precautions can result in serious injury or death.

You can find a digital copy of the manual at the following web address:

www.infentorides.com

PLEASE PRINT OUT THE MANUAL AND KEEP THE MANUAL AND THIS **SAFETY WARNING** IN A SAFE LOCATION FOR FUTURE REFERENCE.

SAFETY SECTION



WARNING! PARENTAL SUPERVISION AND APPROPRIATE USE

Like any moving product, rides made from Infento parts can be dangerous if due care and attention is not paid. To reduce the risk of serious injury: use only under close adult supervision. Parents must review the following warnings and instructions with each Infento ride that is being built. It is your responsibility to review this information and make sure that all riders understand all warnings, cautions, instructions and safety topics, and assure that young riders are able to safely and responsibly use this product. Infento recommends that you periodically review and reinforce the information in this manual with younger riders, and that you inspect and maintain your child's Infento rides to insure their safety.

WARNING! RIDING ON INFENTO RIDES CAN BE A DANGEROUS ACTIVITY

Riding on Infento rides can be a dangerous activity. Certain conditions may cause the equipment to fail without fault of the manufacturer. Rides made from Infento parts can and are intended to move, and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such things occur you can be seriously injured or die, even when using safety equipment and other precautions. Ride at your own risk and use common sense.

WARNING! NO LIABILITY FOR CONSTRUCTED RIDES THAT DIFFER FROM OUR MANUALS

The rides that you can find in our manuals have been tested by official independent testing agencies. We will not be responsible or liable, directly or indirectly, in any way for any loss or damage of any kind incurred as a result of your decision to build constructions or rides that differ from the official rides that we show in our manuals.

ASSEMBLY – SUBSECTION

WARNING! OUR KITS CONTAIN SMALL PARTS

This package contains small parts which, before assembly, present a choking hazard to children under the age of three. Care should be taken

during unpacking and assembly to insure that all small parts and plastic bags are accounted for and kept out of the reach of children.

WARNING! TO AVOID SERIOUS INJURY:

1. Toys are to be assembled by an adult using Infento manuals.
2. All fasteners (bolts and nuts) should be fully tightened.
3. It is the responsibility of the adult who assembles this bicycle to properly install all parts included in the factory sealed shipping carton and to make the adjustments to the functional parts such as handle bar and seat and chain when necessary.

USE – SUBSECTION

WARNING! TO AVOID SERIOUS INJURY:

1. Continuous adult supervision is required.
2. Only ride constructed rides that have been built according to the instructions given in the official Infento manual.
3. Never exceed the maximum weight. You can find the maximum weight for every specific ride in our manual.
4. Always check the manual to see the minimum and maximum age as well as the minimum and maximum length for every specific ride.
5. Always wear safety equipment such as a helmet, knee pads and elbow pads. We recommend riders always wear a properly fitted helmet that complies with local or national guidelines or laws. Keep chinstrap of helmet securely buckled.
6. Always wear closed toed shoes (lace-up shoes with rubber soles), never ride barefooted or in sandals, and keep shoe laces tied and out of the way of the wheels.
7. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking and visibility.
8. Excessive exposure to sunlight, temperatures below 0 degrees Celsius, water, sand, gravel, dirt, leaves, and other debris can damage, shrink, expand or weaken parts. Keep your ride in a dry environment with proper heating.
9. Avoid sharp bumps, drainage grates and sudden surface changes. Your Infento ride may suddenly stop.
10. Ride on smooth, paved surfaces away from motor vehicles. Wet, slick or uneven and rough

surfaces may impair traction and contribute to possible accidents.

11. Never risk damaging surfaces, such as carpet or flooring, by use of an Infento ride indoors.
12. Never use near motor vehicles, streets, roadways, alleys, swimming pool areas, hills, steps, sloped driveways, inclines and public highways.
13. Watch out for pedestrians, skaters, skateboards, scooters, bikes, children or animals who may enter your path, and respect the rights and property of others.
14. Avoid excessive speed associated with downhill rides.
15. Do not use at night or in periods with reduced visibility.
16. Before every use, please make sure that the complete ride and all joints have been assembled tightly, as with use, joints may wear out.
17. Before using your Infento ride, please check that the screws are tightened securely.
18. It's your own responsibility if you modify the product other than manufacturer's instructions.
19. Maintain a hold on the handlebars at all times.
20. Brake will get hot from continuous use. Do not touch after braking.
21. Periodically check hardware and tighten if necessary. Replace worn or broken parts immediately.
22. Skill is required to avoid falls or collision causing injury to the user and third parties.
23. Check operation of breaks every time before bicycle is ridden.
24. Check local laws before you start with riding.
25. Never tow wagons, other vehicles, or children on skates or skateboards.
26. Make certain that anyone who uses an Infento ride has been fully instructed in its operation.
27. Instruct your child on how to use the breaks.
28. Do not perform stunts.
29. Never use headphones or a cell phone when riding.
30. Only one rider at a time on an Infento ride.
31. Do not allow children to stand on the product at any time.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES RISK OF SERIOUS INJURY. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

SAFETY SECTION



OUR KITS CONTAIN SMALL PARTS

This package contains small parts which, before assembly, present a choking hazard to children under the age of three. Care should be taken during unpacking and assembly to insure that all small parts and plastic bags are accounted for and kept out of the reach of children.

QUESTIONS? HELP NEEDED?

You can email us at:
support@infentorides.com
and our team will assist you as soon as possible.



MAINTENANCE | INSTRUCTION



1. Oil or grease moving parts periodically.
2. Check nuts and bolts often and tighten if necessary.
3. Any parts showing evidence or wear should be replaced immediately.
4. Follow closely the assembly instructions pertaining to the proper adjustments of parts
5. Periodically check the brake system for proper function
6. Periodically check the steering mechanism for proper function
7. Check the air pressure in the tires to be the amount specified in the manual
8. Periodically check the bicycle's tooth belt to be sure that it is not too loose which could allow the chain to slip off the sprockets.

RECOMMENDED TOOLS




4 x Allen key
3, 4, 5, 6 mm



1 x Tapeline



1 x T-handle
for Allen key




5 x Wrench
10, 13, 14, 15, 19 mm




1

ride **B-TRIKE**



If you have the 520 mm profile in your kit, please skip to the next step. If not, you can construct it using the profile connectors A and B, as shown below.




A

NOTE
The Profile connector (part A) has the infento word-emblem on it and doubles as a T-joint.

B

C

D




TOP 3 REQUIREMENTS MAKING A GREAT INFENTO EXPERIENCE:



1

Tighten bolts with full force (15Nm) to prevent them from coming loose.



2

Constructing and playing always under supervision of an adult.



3

Check frequently if all parts are still firmly tightened and function properly.








2

ride **B-TRIKE**


- T-Positioning block 2x
- Bolt M8x20 1x
- Profile nut short 1x
- Multi angle joint 1x
- Profile 20.47 inch | 520 mm 1x



NOTE
Place the profile connector in the same orientation as shown here, then follow step A.



Double check here:
Does your result looks exactly like the image at the bottom of the page?








3

ride **B-TRIKE**


- 
 T-Positioning block 2x
- 
 Bolt M8x20 1x
- 
 Profile nut short 1x
- 
 Multi angle joint 1x

First, get all required materials stated here and then follow the instructions.



Tighten the bolts with full force. Ensure that you hold the long side of the Allen key in your hand as this enables you to exert greater force.

TIP!
 It is best to tighten the bolt in such a way that you can still move the block and easily determine the right position with a tape measure. After that, you can then tighten the block further and you verify whether the size is correct.









4

ride B-TRIKE

- T-Positioning block 2x
- Bolt M8x20 1x
- Profile nut short 1x
- Multi angle joint 1x






Double check here:
Does your result looks exactly like
the image at the bottom of the
page?




5

ride **B-TRIKE**

- 
T-Positioning block 2x
- +
- 
Bolt M8x20 1x
- +
- 
Profile nut short 1x
- +
- 
Multi angle joint 1x



The plastic parts of Infento are made using injection moulding technology where molten plastic is pressed under high pressure into a mould. A mould consists of steel blocks in which a shape is recessed.







6


ride **B-TRIKE**

- 8x T-Positioning block
- 2x Bolt M8x45
- 2x 0,2 in | 5 mm profile spacer
- 2x T-joint
- 2x Bearing block 40x40_Hexa 19

Depending on your Kit, the T-joint might look like this. The new T-joint doubles as a profile connector (part A)



The positioning blocks are some of the smallest Infento parts but they are also some of the most important. They ensure that everything connects to each other properly. This prevents parts from twisting and coming loose when under pressure. Therefore, always use at least two positioning blocks per block.



2x




7




ride B-TRIKE



1x
Profile nut short



Use the Allen key handle so you can tighten the bolt well.






8




ride B-TRIKE



1x
Profile nut short



Use the Allen key handle so you can tighten the bolt well.






9


ride *B-TRIKE*



Bearing 2x
protection cap



The positioning blocks are some of the smallest Infento parts but they are also some of the most important. They ensure that everything connects to each other properly. This prevents parts from twisting and coming loose when under pressure. Therefore, always use at least two positioning blocks per block.









10

ride B-TRIKE

- T-Positioning block 2x
- Bolt M8x20 1x
- Profile nut short 1x
- Multi angle joint 1x









11

ride **B-TRIKE**


-  2x
-  1x
-  1x
-  1x







12

ride **B-TRIKE**

-  +
 -  +
 -  +
 - 
- T-Positioning block 4x Bolt M8x20 (low head) 2x L-joint 2x Profile 1.57 inch | 40 mm 1x



The positioning blocks are some of the smallest Infento parts but they are also some of the most important. They ensure that everything connects to each other properly. This prevents parts from twisting and coming loose when under pressure. Therefore, always use at least two positioning blocks per block.








13

ride B-TRIKE


- 
T-Positioning block 2x
- 
Bolt M8x20 1x
- 
Profile nut short 1x
- 
Multi angle joint 1x











14

ride B-TRIKE



If you have the **560 mm** profile in your kit, please skip to the next step. If not, you can construct it using the profile connectors A and B, as shown below.








2x



15

ride B-TRIKE

- T-Positioning block 8x
- Bolt M8x20 (low head) 2x
- Bolt M8x20 2x
- Profile nut short 2x
- Multi angle joint 2x
- Profile 22.05 inch | 560 mm 2x









16

ride *B-TRIKE*


-  4x
-  2x
-  2x
-  2x












17

ride B-TRIKE

- 
 T-Positioning block 4x
- 
 Locknut M8 2x
- 
 Bolt M8x20 2x
- 
 Bolt M8x35 2x
- 
 Multi angle joint 2x
- 
 Knurled disc 1 stripe 2x



There are two types of knurled discs. Please see education section.








18

ride *B-TRIKE*

- T-Positioning block 8x
- Bolt M8x20 4x
- Multi angle joint 4x
- Profile 4.72 inch | 120 mm 2x



2x











19

ride **B-TRIKE**

- 
 Positioning block 2x
- 
 Locknut M8 4x
- 
 Bolt M8x25 1x
- 
 Bolt M8x35 3x
- 
 Knurled disc 1 stripe 3x
- 
 Multi angle joint 2x



There are two different knurled discs. One for each corner ending in a 5 (5-15-25-etc. degrees), which has one stripe round the outside, and one for each corner that ends in a 0 (0-10-20-etc degrees), which has two stripes round the outside.











20

ride B-TRIKE


- Positioning block 2x
- Locknut M8 4x
- Bolt M8x25 1x
- Bolt M8x35 3x
- Knurled disc 1 stripe 3x
- Multi angle joint 2x









21

ride *B-TRIKE*

-  +
 -  +
 -  1x
 -  1x
 -  1x
- Locknut M6 5x Bolt M6x16 5x Toothed belt pulley 26T 1x Freewheel 1x Toothed belt 136T 1x










22

ride **B-TRIKE**






-  2x Bolt M6x20
-  + 1x Clamping part holes with M6 thread
-  + 1x Clamping part holes without thread
-  1x Spacer 0.2 inch | 5 mm
-  1x Spacer 0.39 inch | 10 mm
-  + 1x Axle 25.51 inch | 648 mm





23

ride B-TRIKE











24

ride B-TRIKE

If your protect cap has a hole, use a M8x12 countersunk bolt to fasten it

-  Bolt M8x20
 - +
 -  Spacer
 - +
 -  Protect cap
 - +
 -  Wheel lock ring 8-42
- 1x 1x 1x 1x









25

ride B-TRIKE

- 
T-Positioning block 2x
- 
Bolt M8x20 (low head) 1x
- 
Profile nut short 1x
- 
L-joint 1x



This side has 3 position holes.





26

ride B-TRIKE



1x


Locknut M8

+





Bolt M8x20
(low head) 1x

+




Brake caliper holder 1x








27

ride B-TRIKE

- 
Bolt M5x6
- +
- 
Bolt M6x16
- +
- 
Conical spring washer M6-10
- +
- 
Caliper shield
- +
- 
Brake caliper









28

ride B-TRIKE

Spacer 1x
1.97 inch | 50 mm

+






Brake disc 1x





29

ride B-TRIKE





30

ride B-TRIKE



Bolt M8x20






1x



Wheel lock ring 8-42

1x









31

ride B-TRIKE









5x
Bolt M6x12





32

ride B-TRIKE





33


ride *B-TRIKE*



Bolt M6x20

2x

+







Clamping part
holes with M6 thread

+



Clamping part
holes without thread

1x








34

ride B-TRIKE

- T-Positioning block 18x
- Bolt M8x20 6x
- Multi angle joint 6x
- Profile 5.51 inch | 140 mm 3x





35

ride *B-TRIKE*



4x

Locknut M8

+



4x





Bolt M8x35

+





4x

Knurled disc 2 stripes



Most nuts that you use for Infento are self-locking. This means that they cannot vibrate loose. On the inside of the bolt you will see a plastic washer that ensures it cannot turn freely, even if there is no tension on the bolt.





36

ride B-TRIKE



 +
Positioning block 4x

 +
Locknut M8 2x

 +
Bolt M8x25 (low head) 2x

 +
L-joint 2x

 +
Multi angle joint 2x





37

ride **B-TRIKE**





 +
T-Positioning block 4x

 +
Bolt M8x20 2x
(low head)

 +
Profile nut short 2x

 +
Protect cap 1x

 +
Profile 1x
9.45 inch | 240 mm








38

ride B-TRIKE

- T-Positioning block 4x
- Bolt M8x20 2x
- Profile nut short 2x
- Bearing block 40x40_8 2x
- Profile 7.87 inch | 200 mm 1x



Use the Allen key handle so you can tighten the bolt well.





39

ride B-TRIKE

6x
T-Positioning block

1x
Bolt M8x20

+

2x
Bolt M8x20
(low head)


+

1x
L-joint


+

1x
Multi angle joint



A



B



C





40

ride *B-TRIKE*



3x

Locknut M8

+



3x




Bolt M8x35

+



3x


Knurled disc 2 stripes









41

ride *B-TRIKE*


-  3x
-  1x
-  1x
-  1x
-  1x





42

ride B-TRIKE




Spacer 3x
0.08inch | 2 mm

+




Spacer 1x
0.2 inch | 5 mm

+





Bearingblock 0x
40x80_hexa 19

A



B

5 mm spacer










43

ride *B-TRIKE*


-  +  +  +  + 
- Bolt M6x12 5x
- Bolt M6x20 2x
- Clamping part holes with M6 thread 1x
- Axle flange 1x
- Toothed belt pulley 46T 1x





44


ride *B-TRIKE*



+



+



+



+



Spacer 2x
0.08inch | 2 mm


Spacer 1x
0.39 inch | 10 mm

Bearingblock 1x
40x80_hexa 19


Pedal right 1x

Crank right 1x



A



B



C





45

ride B-TRIKE



+







+



T-Positioning block 4x

Bolt M8x20 3x

Washer M8-24 1x










46

ride *B-TRIKE*

 + 
Bolt M8x20 4x Profile nut short 4x








47

ride B-TRIKE

If your Kit contains a white fastener bag with 12 Nock Washers, please follow the steps on this page. If not, please skip to the next page of the manual.





2x
Nock washer M8-16









48

ride **B-TRIKE**

-  4x
-  2x
-  2x
-  2x
-  1x


If your U-block or Kit doesn't have the M8-16 Nock Washers, you can use the regular M8-16 washers as shown here.










49

ride *B-TRIKE*

-  2x
-  2x
-  4x
-  2x





50



ride B-TRIKE

T-Positioning block 4x

Bolt M8x20 (low head) 2x

L-joint 2x

Profile 2x
7.87 inch | 200 mm





51

ride *B-TRIKE*



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile nut short 1x





52

ride B-TRIKE



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile nut short 1x










53

ride B-TRIKE

- 
6x
T-Positioning block
- +
- 
2x
Bolt M8x20
(low head)
- +
- 
1x
Protect cap
- +
- 
2x
L-joint
- +
- 
2x
Parallel clamp joint







54

ride *B-TRIKE*


- Positioning block 4x
- Bolt M8x25 (low head) 1x
- Bolt M8x45 1x
- Axle plate 2x
- Handlebar extension 1x
- Handlebar short 2x








55

ride **B-TRIKE**

-  5x
-  1x
-  1x
-  1x
-  1x
-  1x





56

ride B-TRIKE



Positioning block



+



T-joint

2x

1x





57

ride B-TRIKE



Bolt M8x40





+

1x



Profile nut short





1x





58

ride **B-TRIKE**





59

ride B-TRIKE





+



Positioning block 2x

T-joint 1x





60

ride B-TRIKE







Bolt M8x40

+

1x



Profile nut short 1x





61

ride *B-TRIKE*



+






+



T-Positioning block 4x

Bolt M8x20 (low head) 1x

L-joint 1x








62

ride B-TRIKE

-  8x
-  2x
-  2x
-  1x
-  1x





63

ride B-TRIKE







+



Bolt M8x20 3x
(low head)

Profile nut short 2x





64

ride B-TRIKE


Positioning block 4x

Bolt M8x25 2x


Locknut M8 2x

Multi angle joint 2x

Axle clamp 2x




2x





65

ride B-TRIKE





+



Spacer 2x
0.2 inch | 5 mm

Axle 1x
6.06 inch | 154 mm





66

ride B-TRIKE



2x

Locknut M8

+



2x





Bolt M8x35

+



2x

Knurled disc 1 stripe










67

ride B-TRIKE


- Bolt M6x25 4x + Bolt M8x20 2x + Locknut M6 4x + Washer M8-24 2x











68

ride B-TRIKE



Belt shield 2x
cap 46T









69

ride B-TRIKE




Belt shield 2x
nylon ring







70

ride *B-TRIKE*



Belt shield
centre 46T






2x





71


ride B-TRIKE










72

ride B-TRIKE



Belt shield 2x
cap 26T









73

ride B-TRIKE



Belt shield 2x
nylon ring







74

ride *B-TRIKE*






Belt shield 2x
centre 26T





75





ride B-TRIKE





76


ride B-TRIKE









77

ride B-TRIKE



Emblem 1x








78

id. 0-TRUKF

If you have this type of seat in your Kit, please skip to the next page. If not, follow the instructions below to construct your seatboard.



=






Put the M6 square nuts in place before inserting the M6x50 bolts.



79

- Square nut M6 4x
- Bolt M6x50 4x
- Seatboard Filler 1x
- Seatboard Tail 1x
- Seatboard Base 1x

If you have this type of seat in your Kit, please skip to the next page. If not, follow the instructions below to construct your seatboard.










80

ride B-TRIKE


-  4x
-  4x
-  1x
-  1x








81

ride B-TRIKE




1x
Brake lever left










82

ride B-TRIKE



Handgrip 2x










83

ride *B-TRIKE*



Brake cable 1x
59.06 in | 1500 mm









84

ride B-TRIKE








4x
Brake cable clip





85

ride B-TRIKE



B-TRIKE^{G2}



THANK YOU FOR READING ME!