

**4-9**  
YEARS

# **BULLDOG**<sup>G3</sup>

CONSTRUCTION MANUAL



**Length** 110 - 138 cm / 43 - 54 inch  
**Max weight** 40 kg / 88 lbs  
**Time to build** 6 hours



World's first real constructible rides



**WARNING - IMPORTANT NOTICE TO PARENTS**

Before you start constructing and use our product, please carefully read the following safety warning and download our manual from our website. This safety warning and manual contains important information relating to your child's safety. It is your responsibility to review this information with your child and make sure they are fully aware of all the warnings before they start riding. Failure to follow instructions and safety precautions can result in serious injury or death.

You can find a digital copy of the manual at the following web address:

**[www.infentorides.com](http://www.infentorides.com)**

**PLEASE PRINT OUT THE MANUAL** AND KEEP THE MANUAL AND THIS **SAFETY WARNING** IN A SAFE LOCATION FOR FUTURE REFERENCE.

# SAFETY SECTION



## **WARNING! PARENTAL SUPERVISION AND APPROPRIATE USE**

Like any moving product, rides made from Infento parts can be dangerous if due care and attention is not paid. To reduce the risk of serious injury: use only under close adult supervision. Parents must review the following warnings and instructions with each Infento ride that is being built. It is your responsibility to review this information and make sure that all riders understand all warnings, cautions, instructions and safety topics, and assure that young riders are able to safely and responsibly use this product. Infento recommends that you periodically review and reinforce the information in this manual with younger riders, and that you inspect and maintain your child's Infento rides to insure their safety.

## **WARNING! RIDING ON INFENTO RIDES CAN BE A DANGEROUS ACTIVITY**

Riding on Infento rides can be a dangerous activity. Certain conditions may cause the equipment to fail without fault of the manufacturer. Rides made from Infento parts can and are intended to move, and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such things occur you can be seriously injured or die, even when using safety equipment and other precautions. Ride at your own risk and use common sense.

## **WARNING! NO LIABILITY FOR CONSTRUCTED RIDES THAT DIFFER FROM OUR MANUALS**

The rides that you can find in our manuals have been tested by official independent testing agencies. We will not be responsible or liable, directly or indirectly, in any way for any loss or damage of any kind incurred as a result of your decision to build constructions or rides that differ from the official rides that we show in our manuals.

### ASSEMBLY – SUBSECTION

## **WARNING! OUR KITS CONTAIN SMALL PARTS**

This package contains small parts which, before assembly, present a choking hazard to children under the age of three. Care should be taken

during unpacking and assembly to insure that all small parts and plastic bags are accounted for and kept out of the reach of children.

## **WARNING! TO AVOID SERIOUS INJURY:**

1. Toys are to be assembled by an adult using Infento manuals.
2. All fasteners (bolts and nuts) should be fully tightened.
3. It is the responsibility of the adult who assembles this bicycle to properly install all parts included in the factory sealed shipping carton and to make the adjustments to the functional parts such as handle bar and seat and chain when necessary.

### USE – SUBSECTION

## **WARNING! TO AVOID SERIOUS INJURY:**

1. Continuous adult supervision is required.
2. Only ride constructed rides that have been built according to the instructions given in the official Infento manual.
3. Never exceed the maximum weight. You can find the maximum weight for every specific ride in our manual.
4. Always check the manual to see the minimum and maximum age as well as the minimum and maximum length for every specific ride.
5. Always wear safety equipment such as a helmet, knee pads and elbow pads. We recommend riders always wear a properly fitted helmet that complies with local or national guidelines or laws. Keep chinstrap of helmet securely buckled.
6. Always wear closed toed shoes (lace-up shoes with rubber soles), never ride barefooted or in sandals, and keep shoe laces tied and out of the way of the wheels.
7. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking and visibility.
8. Excessive exposure to sunlight, temperatures below 0 degrees Celsius, water, sand, gravel, dirt, leaves, and other debris can damage, shrink, expand or weaken parts. Keep your ride in a dry environment with proper heating.
9. Avoid sharp bumps, drainage grates and sudden surface changes. Your Infento ride may suddenly stop.
10. Ride on smooth, paved surfaces away from motor vehicles. Wet, slick or uneven and rough

surfaces may impair traction and contribute to possible accidents.

11. Never risk damaging surfaces, such as carpet or flooring, by use of an Infento ride indoors.
12. Never use near motor vehicles, streets, roadways, alleys, swimming pool areas, hills, steps, sloped driveways, inclines and public highways.
13. Watch out for pedestrians, skaters, skateboards, scooters, bikes, children or animals who may enter your path, and respect the rights and property of others.
14. Avoid excessive speed associated with downhill rides.
15. Do not use at night or in periods with reduced visibility.
16. Before every use, please make sure that the complete ride and all joints have been assembled tightly, as with use, joints may wear out.
17. Before using your Infento ride, please check that the screws are tightened securely.
18. It's your own responsibility if you modify the product other than manufacturer's instructions.
19. Maintain a hold on the handlebars at all times.
20. Brake will get hot from continuous use. Do not touch after braking.
21. Periodically check hardware and tighten if necessary. Replace worn or broken parts immediately.
22. Skill is required to avoid falls or collision causing injury to the user and third parties.
23. Check operation of breaks every time before bicycle is ridden.
24. Check local laws before you start with riding.
25. Never tow wagons, other vehicles, or children on skates or skateboards.
26. Make certain that anyone who uses an Infento ride has been fully instructed in its operation.
27. Instruct your child on how to use the breaks.
28. Do not perform stunts.
29. Never use headphones or a cell phone when riding.
30. Only one rider at a time on an Infento ride.
31. Do not allow children to stand on the product at any time.

**FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES RISK OF SERIOUS INJURY. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.**

# SAFETY SECTION



## OUR KITS CONTAIN SMALL PARTS

This package contains small parts which, before assembly, present a choking hazard to children under the age of three. Care should be taken during unpacking and assembly to insure that all small parts and plastic bags are accounted for and kept out of the reach of children.

## QUESTIONS? HELP NEEDED?

You can email us at:  
**[support@infentorides.com](mailto:support@infentorides.com)**  
and our team will assist you as soon as possible.



## MAINTENANCE | INSTRUCTION



1. Oil or grease moving parts periodically.
2. Check nuts and bolts often and tighten if necessary.
3. Any parts showing evidence or wear should be replaced immediately.
4. Follow closely the assembly instructions pertaining to the proper adjustments of parts
5. Periodically check the brake system for proper function
6. Periodically check the steering mechanism for proper function
7. Check the air pressure in the tires to be the amount specified in the manual
8. Periodically check the bicycle's tooth belt to be sure that it is not too loose which could allow the chain to slip off the sprockets.

### RECOMMENDED TOOLS




**4 x Allen key**  
3, 4, 5, 6 mm



**1 x Tapeline**



**1 x T-handle**  
for Allen key



**5 x Wrench**  
10, 13, 14, 15, 19 mm



1

ride **BULLDOG**



T-Positioning block 4x



Positioning block 4x



Bolt M8x40 2x




Swivel plate 4x




Multi angle joint 2x

First, get all required materials stated here and then follow the instructions.



Double check here:  
Does your result looks exactly like the image at the bottom of the page?

2x




In frames like this you can find some background facts about technique.

# TOP 3 REQUIREMENTS MAKING A GREAT INFENTO EXPERIENCE:



1

**Tighten bolts with full force (15Nm) to prevent them from coming loose.**



2

**Constructing and playing always under supervision of an adult.**



3


**Check frequently if all parts are still firmly tightened and function properly.**






2

ride **BULLDOG**



If you have the 520 mm profile in your kit, please skip to the next step. If not, you can construct it using the profile connectors A and B, as shown below.




**A**

**NOTE**  
The Profile connector (part A) has the infento word-emblem on it and doubles as a T-joint.

**B**

**C**

**D**












3

ride BULLDOG

NOTE  
Place the profile  
connector in the same  
orientation as shown  
here, then follow step A.



Double check here:  
Does your result looks exactly like  
the image at the bottom of the  
page?










# 4

ride **BULLDOG**



1x  
Profile nut short







The plastic parts of Infento are made using injection moulding technology where molten plastic is pressed under high pressure into a mould. A mould consists of steel blocks in which a shape is recessed.



5

ride **BULLDOG**

- T-Positioning block 4x
- Bolt M8x20 2x
- Profile nut short 2x
- Multi angle joint 2x



The plastic parts of Infento are made using injection moulding technology where molten plastic is pressed under high pressure into a mould. A mould consists of steel blocks in which a shape is recessed.








6

ride **BULLDOG**

-  8x
-  2x
-  2x
-  2x

Use the Allen key handle so you can tighten the bolt well.










# 7

ride **BULLDOG**

-  +
  -  +
  -  +
  - 
- Locknut M8 2x      Bolt M8x60 2x      Washer M8-16 4x      Steering arm 2x 2.76 inch | 70 mm






Between the U-block and the block bearing there have to be two washers. They ensure that there is space between the two blocks. Without it, the blocks would rub against each other, damage and twist heavily. With washers the gap is filled perfectly and you can tighten them securely.




8

ride **BULLDOG**




2x






9

ride **BULLDOG**

-  2x
-  2x
-  2x


**A**




Depending on your Kit, the knurled discs can be of a different type, looking like this:





**B**




 

**C**





**D**



15°







There are two types of knurled discs. Please see education section.





10

ride **BULLDOG**









11

ride BULLDOG

-  4x
-  2x
-  2x
-  2x





**TIP!**  
It is best to tighten the bolt in such a way that you can still move the block and easily determine the right position with a tape measure. After that, you can then tighten the block further and you verify whether the size is correct.






12

ride **BULLDOG**




The positioning blocks are some of the smallest Infento parts but they are also some of the most important. They ensure that everything connects to each other properly. This prevents parts from twisting and coming loose when under pressure. Therefore, always use at least two positioning blocks per block.







13

ride **BULLDOG**

-  4x
-  2x
-  2x
-  1x





14

ride **BULLDOG**




2x

+






2x

+



2x

Knurled disc 2 stripes



There are two different knurled discs. One for each corner ending in a 5 (5-15-25-etc. degrees), which has one stripe round the outside, and one for each corner that ends in a 0 (0-10-20-etc degrees), which has two stripes round the outside.



15

ride **BULLDOG**



2x




2x




2x

Knurled disc 2 stripes


A




B



C



90°









16

ride BULLDOG

- T-Positioning block 4x
- Bolt M8x20 2x
- Profile nut short 2x
- Multi angle joint 2x
- Profile 5.12 inch | 130 mm 1x









17

ride BULLDOG

-   
T-Positioning block 2x
- +
-   
Bolt M8x20 1x
- +
-   
Profile nut short 1x
- +
-   
Multi angle joint 1x





18

ride **BULLDOG**



2x

+



2x

+








2x

Locknut M8

Bolt M8x35






Knurled disc 2 stripes





# 19






ride **BULLDOG**





20

ride BULLDOG





21


ride **BULLDOG**



Bolt M8x20

2x


+



Spacer  
0.08inch | 2 mm




2x

+



Wheel lock ring 8-42


2x







22

ride **BULLDOG**

-  5x
-  1x
-  1x
-  1x
-  1x
-  1x



Please make sure you use a nylock bolt when indicated, the nylon resists turning. These bolts can be recognized by their red or blue dot.





23

ride BULLDOG



T-Positioning block 2x

+



Bolt M8x20 (low head) 1x

+




Profile nut short 1x

+




L-joint 1x


A




B



C



0.71" | 18 mm





24

ride **BULLDOG**



+






+



T-Positioning block 4x

Bolt M8x20 (low head) 1x

Bearing protection cap 1x










25

ride BULLDOG


-   
T-Positioning block 3x
- +
-   
Bolt M8x20 (low head) 2x
- +
-   
Profile nut short 2x
- +
-   
L-joint 1x







26

ride **BULLDOG**

-   
Positioning block 4x
-   
Locknut M8 1x
-   
Bolt M8x40 1x
-   
Swivel plate 2x
-   
Brake caliper holder 1x







27

ride **BULLDOG**


-  1x
- +
-  1x
- +
-  1x








28

ride **BULLDOG**






-   
Bolt M5x6
- +
-   
Bolt M6x16
- +
-   
Conical spring washer M6-10
- +
-   
Caliper shield
- +
-   
Brake caliper





29


ride BULLDOG






30

ride BULLDOG








+



Spacer 2x  
0.39 inch | 10 mm







Brake disc 1x





31

ride **BULLDOG**









32

ride **BULLDOG**



5x  
Bolt M6x12








33

ride BULLDOG


-   
1x  
T-Positioning block
- +
-   
1x  
Bolt M8x20  
(low head)
- +
-   
1x  
Profile nut short
- +
-   
1x  
L-joint







**34**

ride **BULLDOG**


-  +
  -  +
  -  +
  -  1x
- Locknut M6 5x      Bolt M6x16 5x      Freewheel 1x      Toothed belt pulley 26T 1x





35

ride BULLDOG






+



Spacer 3x  
0.08inch | 2 mm

Spacer 2x  
0.2 inch | 5 mm







36

ride **BULLDOG**

- T-Positioning block 5x
- Bolt M8x20 (low head) 1x
- Bolt M8x20 nylock 1x
- L-joint 1x
- Bearing block 40x40\_8 1x
- Profile 6.30 inch | 160 mm 1x










37

ride BULLDOG

- T-Positioning block 6x
- Bolt M8x20 (low head) 2x
- Bolt M8x60 1x
- Profile nut short 1x
- Bearing protection cap 1x
- Washer M8-30 1x









38

ride BULLDOG

- Positioning block 2x
- Bolt M8x25 (low head) 1x
- Locknut M8 1x
- Bearing protection cap 1x
- L-joint 1x
- Bearing block 40x40\_Hexa 19 1x





39


ride **BULLDOG**



+





+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile 1x  
11.02 inch | 280 mm







40

ride **BULLDOG**

- T-Positioning block 4x
- Bolt M8x20 (low head) 1x
- Bolt M8x20 1x
- L-joint 1x
- Multi angle joint 1x
- Profile 5.51 inch | 140 mm 1x





# 41

ride **BULLDOG**



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x


Profile nut short 1x







42

ride **BULLDOG**

-  4x
-  1x
-  1x
-  1x
-  1x
-  1x





# 43

ride **BULLDOG**



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile nut short 1x





44

ride **BULLDOG**




 +  
Positioning block 4x

 +  
Locknut M8 2x

 +  
Bolt M8x25 (low head) 2x

 +  
L-joint 2x

 +  
Multi angle joint 2x





# 45

ride **BULLDOG**



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile nut short 1x





# 46

ride **BULLDOG**



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x


Profile nut short 1x







47


ride BULLDOG

-   
 Positioning block 2x
-   
 Bolt M8x25 (low head) 1x
-   
 Locknut M8 1x
-   
 Bearing protection cap 1x
-   
 L-joint 1x
-   
 Bearing block 40x40\_Hexa 19 1x

This side has 3 position holes.




- 

1 take a 5mm Allen key, slide the nut on it
- 

2 stick the Allen key through the part
- 

3 let the nut slide down












# 49

ride **BULLDOG**


- Bolt M6x8 5x
- Bolt M6x20 2x
- Clamping part holes with M6 thread 1x
- Axle flange 1x
- Steering plate 1x
- Axle 21.65 inch | 550 mm 1x





50

ride **BULLDOG**






Spacer 4x  
0.39 inch | 10 mm

+



Spacer 1x  
1.97 inch | 50 mm





# 51

ride **BULLDOG**



2x

Locknut M8


+



2x





Bolt M8x35

+



2x


Knurled disc 2 stripes









52

ride **BULLDOG**

-  4x
-  2x
-  2x
-  2x
-  1x









53

ride **BULLDOG**

-   
T-Positioning block    4x
-   
Bolt M8x20 nylock    1x
-   
Protect cap    1x
-   
Multi angle joint    1x



 If your protect cap has a hole, use a M8x12 countersunk bolt to fasten it







54

ride **BULLDOG**

- T-Positioning block 4x
- Bolt M8x20 (low head) 1x
- Bolt M8x20 1x
- L-joint 1x
- Multi angle joint 1x
- Profile 2.36 inch | 60 mm 1x









55

ride **BULLDOG**


-  2x
-  1x
-  1x







**56**

ride **BULLDOG**

-  4x
-  1x
-  1x
-  1x
-  1x
-  1x  
2.36 inch | 60 mm





57

ride BULLDOG



+







+



T-Positioning block 2x

Bolt M8x20 (low head) 1x

Profile nut short 1x










58

ride BULLDOG

- Locknut M8 2x + Bolt M8x35 3x + Knurled disc 1 stripe 1x + Knurled disc 2 stripes 2x





59

ride BULLDOG



Rod end M8 2x  
internal thread

+



M8 Threaded rod 2x  
3.94in | 100mm

+



Nut M8


+

6x




Rod end M8 2x  
external thread

+




Steering  
turnbuckle 2x  
3.94 in | 100mm


A



B



C





**60**

ride **BULLDOG**



Nut M8

8x







Conical spring  
washer M8-13

8x



Bolt M8x45

4x










61

ride BULLDOG



2x  
Locknut M8










62

ride BULLDOG





Locknut M8 2x





63

ride BULLDOG





64

ride **BULLDOG**



Locknut M8



+



Bolt M8x60

2x

2x









65

ride BULLDOG

-  Bolt M8x20 3x
-  Washer M8-24 1x
-  Pedal right 1x
-  Crank right 1x
-  Axle 6.77 inch | 172 mm 1x







66

ride **BULLDOG**

-   
Bolt M6x12    5x
-   
Bolt M6x20    2x
-   
Clamping part  
holes with M6 thread    1x
-   
Axle flange    1x
-   
Toothed  
belt pulley 46T    1x








67

ride **BULLDOG**



Spacer 1x  
0.2 inch | 5 mm








68

ride BULLDOG


- Spacer 2x  
0.08inch | 2 mm
- +
- Spacer 1x  
0.2 inch | 5 mm
- +
- Spacer 1x  
0.39 inch | 10 mm
- +
- Bearingblock 2x  
40x80\_hexa 19










69

ride **BULLDOG**

-  +
  -  +
  -  +
  -  +
  -  +
  - 
- T-Positioning block 4x      Bolt M8x20 3x      Washer M8-24 1x      Spacer 0.04inch | 1mm 1x      Pedal left 1x      Crank left 1x





70

ride BULLDOG



+







Bolt M8x20

4x

Profile nut short

4x









71

ride BULLDOG




Toothed belt 118T 1x











72

ride BULLDOG



Belt shield 2x  
cap 46T









73

ride **BULLDOG**




Belt shield 2x  
nylon ring







74

ride **BULLDOG**



Belt shield  
centre 46T




2x





75


ride BULLDOG










76

ride BULLDOG



Belt shield 2x  
cap 26T









77

ride BULLDOG



Belt shield 2x  
nylon ring







78

ride **BULLDOG**



Belt shield 2x  
centre 26T










79

ride BULLDOG


Belt shield profile top 2x 11.69 inch | 297 mm + Belt shield profile bottom 2x 11.69 inch | 297 mm









# 80

ride **BULLDOG**

-  6x
-  3x
-  2x
-  1x
-  2x
-  1x





81

ride **BULLDOG**

 + 2x  
Positioning block


 + 1x  
Locknut M8


 + 1x  
Bolt M8x25  
(low head)

 + 1x  
L-joint



 + 1x  
Axle clamp

### NUT-IN-PART-TRICK

1  take a 5mm  
Allen key, slide  
the nut on it

2  stick the Allen  
key through  
the part

3  let the nut  
slide down







82

ride **BULLDOG**

-   
Positioning block 2x
-   
Bolt M8x25 1x
-   
Axle plate 1x
-   
Multi angle joint 1x
-   
Handlebar short 1x










# 83

ride **BULLDOG**

- |  |   |  |   |   |   |  |   |  |  |    |  |              |  |    |  |        |  |    |  |                 |
|--|---|--|---|---|---|--|---|--|--|----|--|--------------|--|----|--|--------|--|----|--|-----------------|
|  | + |  | + |  | + |  | + |  |  |    |  |              |  |    |  |        |  |    |  |                 |
| Locknut M6   |   | 4x   |   | Bolt M6x25  |   | 4x   |   | Bolt M8x20   |  | 1x |  | Washer M8-24 |  | 1x |  | Spacer |  | 1x |  | 0.04inch   1 mm |



Leave a gap of at least 0.5mm when tightening the bolts.







84

ride **BULLDOG**

-  2x
-  1x
-  1x
-  1x








85

ride **BULLDOG**

-  +
  -  +
  -  +
  -  2x
- 4x T-Positioning block      2x Bolt M8x20      1x Profile nut short      2x Multi angle joint





86

ride **BULLDOG**



2x



2x






2x

Locknut M8

Bolt M8x35

Knurled disc 1 stripe








87

- Square nut M6 4x
- Bolt M6x50 4x
- Seatboard Filler 1x
- Seatboard Tail 1x
- Seatboard Base 1x

If you have this type of seat in your Kit, please skip to the next page. If not, follow the instructions below to construct your seatboard.





88

ride BULLDOG



Nut M8

1x

+



Bolt M8x20

1x

+



Bolt M8x25

1x


+



Profile nut short




1x

+



Ducktail board + foam

1x





89

ride **BULLDOG**



Positioning block 1x

Bolt M8x25 1x

Axle plate 1x

Multi angle joint 1x

Handlebar short 1x





90

ride **BULLDOG**



1x

Locknut M8

+



1x



Bolt M8x35

+



1x

Knurled disc 1 stripe





91

ride **BULLDOG**

-  +
-  +
-  +
-  +
-  +
- 

Positioning block 1x



Bolt M8x45 1x

Axle plate 1x

Multi angle joint 1x

Handlebar extension 1x

Handlebar short 1x





92

ride **BULLDOG**



1x



1x





1x

Locknut M8

Bolt M8x35


Knurled disc 1 stripe








93

ride BULLDOG




Handgrip 1x






94

ride BULLDOG







Handgrip

1x



Brake lever left






1x





95


ride **BULLDOG**









96

ride BULLDOG



2x  
Brake cable clip






1x  
Brake cable  
39.37 in | 1000 mm





97


ride **BULLDOG**







98

ride BULLDOG



Emblem 1x



# BULLDOG<sup>G3</sup>



THANK YOU FOR READING ME!